

# Plain Mount Flat Cut MINI Letters

## Installation Guide

### Flat, Smooth Interior Surface

Small Metal letters with NO hardware.

**Tools Required:** Stencil Guide, level, masking tape, tape measure, cleaning cloth, adhesive, quality VHB tape.



Videos



#### 1. CLEAN Mounting Surface

Clean and prepare mounting surface before starting your install.

**Tip:** Surface should be flat, clean and free of excess dust or moisture.



#### 2. POSITION and Stencil Guide

A Stencil Guide is recommended to properly install small flat letters. Layout, level and securely tape your guide flat to mounting surface. Check spelling, spacing and kerning of letters on guide.



#### 3. APPLY Adhesive / Tape to Letters

Small MINI letters can be installed with a quality VHB Tape, adhesive or a combination of the two. Be sure to use a quality VHB tape and adhesive that will bond to the metal and your mounting surface. Install one letter at a time.

#### 4. TAPE Letters to Secure

Using long strips of tape, securely tape letters to wall using guide. Stand back and perform a visual check to make sure letters are straight. Lift tape and reposition letters as needed to set straight.



Perform a final check, from a distance, to insure proper spelling & spacing.

#### 5. PRESS Letters to Set

After letters are aligned properly on wall, apply pressure to face of each letter.



#### 6. REMOVE Masking Tape & Clean Letters

After adhesive sets (letters do not move), remove masking tape from letters. Clean off letter faces with a mild dish soap and water - wipe in same direction as letter grain to help prevent scratching letter faces.